



Instructions – Signage Label Holder

Slide the acrylic cover out, remove the protective film, slide your artwork in and replace the cover.

The Label Holder should be fixed to the wall in relative proximity to the artwork on display.